



DOOR NUMBERING AND SCHEDULING

RECOMMENDATION:

1. Each door opening on floor plans should be designated by a different number.
2. Door schedule should contain these numbers in consecutive order with all requirements for each particular opening number appearing on the line item.

COMMENTS:

- A. Different number for each opening will assure proper coordination among millwork sub, door supplier, hardware supplier and metal frame supplier.
- B. On cartoned and/or numbered doors, contractor at jobsite will have easier job in distribution of doors to appropriate opening.
- C. Door lights, louvers, undercuts, "B" label, acoustical, etc. indicated as such on each appropriate numbered door schedule line item will assure one source of information for each opening.